


Division of Mittler Corp. P.O. Box 110 Foristell, Missouri 63348 10 Cooperative Way Wright City, MO 63390

(636) 745-7757 800-467-2464 Fax: (636) 745-2874

75010 Honda Linkage Kit



- **1.** Remove the stamped factory linkage plate and related hardware.
- 2. Check your carburetor and confirm the throttle arm (black plastic molded arm on the top of the throttle shaft) is in good working condition.
- 3. Install the Linkage Bridge to your engine using the two supplied metric socket head bolts. A drop of thread locking compound on each bolt is recommended to prevent bolts from coming loose from vibration and harmonics.
- 4. Install the Cable Adjustment Block to the engine using the factory bolt that was removed in step 1.
- 5. Bolt the Linkage Arm to the Linkage Bridge using the supplied Shoulder Bolt. Use a small drop of thread locking compound on the threads.
- 6. The Throttle Stop Eccentric can now be bolted to the Linkage Bridge using the supplied button head bolt. Do Not fully tighten the bolt until the final step. This eccentric is used as a throttle stop to prevent broken or worn carburetor parts as well as to set wide open throttle to the best performance position.
- 7. Bend your Linkage Rod to fit from the Linkage Arm to the throttle arm on the carburetor. It is important this fits proper to prevent linkage failure. We have formed one end of the linkage rod to fit the Linkage Arm. Each application is slightly different and will require the user to complete the bending on the throttle arm end.
- 8. Now that the Linkage Rod is installed you can rotate the Throttle Stop Eccentric and tighten at wide open throttle or your desired throttle position.