




(636) 745-7757 Fax: (636) 745-2874

P.O. Box 110 Foristell, Missouri 63348 10 Cooperative Way Wright City, MO 63390


2900-300 English Wheel Stand Assembly Instructions

Kit Includes:

1 ea. Rear "H" frame 28 ea. 5/16" Nuts 1 ea. Front frame 24 ea. 3/8" Flat Washer 1 ea. Top tray 8 ea. 5/16" -18 x3" Bolts Bottom tray 2 ea. Swivel Casters, Locking 1 ea. 20 ea. 5/16-18 x 1" Bolts 2 ea. Rigid Caster 28 ea. 5/16" Lock washers Instruction Sheet 1ea.




2. Lay the "H" Frame down like shown below. Attach the lower and upper trays using the 3" long bolts. Be sure to put a 3/8" flat washer on both the top & bottom of the bolt. Slip a lock washer on each bolt and then thread a nut on by hand. **DO NOT TIGHTEN NUTS YET!**




3. Attach the front frame to the top and bottom tray using the same procedure as before. Once all bolts, washers & nuts are started tighten them down.



4. Install the casters using the 1" long bolts, lock washer and nut. The swivel caster go on the "H" frame, this is the back of the stand. This will give you the most stability when using your machine. Attach the rigid caster to the front frame using the 1" long bolts, lock washers and nuts. Be sure to install the bolts from the caster side on the swivel casters.



5. Turn stand over and set on the casters. Double check that all nuts are tight. Carefully set the English Wheel Machine on the stand and line up the holes in the mounting feet with the holes in the upper tray. Use 4 of the 1" long bolts with flat washers on them and slip into the holes. Put a flat washer, lock washer and nut on the bottom of the bolts. Once all the bolts are installed tighten them.



Thank You for Your Purchase.

We appreciate your business. If have any questions, comments or suggestions please contact us.