



### **Dash Panel Wiring Instruction**

- Oil Pressure Gauge - Red Wire Loom -**                      *Connect to the ignition switch*
- Water Temperature - Yellow Wire Loom -**                      Connect to water temp sender unit
- Oil Temperature - White Wire Loom -**                      Connect to oil temperature sender unit

Tanner Racing Products, Inc.  
Tech Line: 800-558-4112



### **Dash Panel Wiring Instruction**

- Oil Pressure Gauge - Red Wire Loom -**                      *Connect to the ignition switch*
- Water Temperature - Yellow Wire Loom -**                      Connect to water temp sender unit
- Oil Temperature - White Wire Loom -**                      *Connect to oil temperature sender unit*

Tanner Racing Products, Inc.  
Tech Line: 800-558-4112



### **Dash Panel Wiring Instruction**

- Oil Pressure Gauge - Red Wire Loom -**                      *Connect to the ignition switch*
- Water Temperature - Yellow Wire Loom -**                      Connect to water temp sender unit
- Oil Temperature - White Wire Loom -**                      *Connect to oil temperature sender unit*

Tanner Racing Products, Inc.  
Tech Line: 800-558-4112