



8" Pads



For Further Technical Assistance Please Contact
Tanner Racing Products by MB
10 Cooperative Way Wright City, MO 63390
P.O. Box 110 Foristell, MO 63348
1-800-467-2464 Fax 1-636-745-2874
www.tannerracing.com
www.mittlerbros.com

8" Jr. RaceScale Instructions



Scaling Instructions

1. Set all scale pads out individually.
2. Plug the cables into the scale pads.
3. Turn the scales on by pushing the On/Off Button. The scales will turn on and read Tanner Racescales and show you the level of the battery. If the battery is low you may want to charge the unit.
4. ZERO the system by pushing the UP or DOWN Arrow and selecting Zero all pads. If you are not using all pads you may individually Zero each pad. After you highlight the choice on the menu you may select it by pushing the OK button. This will then display zero's on the locations selected.
5. Put your vehicle on the scales and the weights will register, the %'s and totals will show on the displays.
6. Shut the scales OFF by pushing the ON/OFF button for 2 seconds and the scales will turn off.
7. Remove the cables from the scale pads and put the unit away. If the scale needs charging you can plug the AC adapter into the scale and the battery voltage bar will display on the top display.

Button Operation

Push this button to turn unit ON

Push and hold for 2 seconds to turn Unit OFF

Select this button as the OK button during the menu functions.

On/Off/Ok



Push this button to enter into the menu.

This button will also allow you to scroll up.



Push this button to enter into the menu.

This button will also allow you to scroll down.

If you have any questions or need technical assistance please call 800-467-2464. Thank you and good luck racing.