

RACESCALES JR

CONGRATULATIONS ON YOUR PURCHASE OF THE LASTEST TECHNOLOGY IN RACESCALES

RACESCALES
MODEL # 50200

FOR FURTHER TECHNICAL ASSISTANCE
PLEASE CONTACT
TANNER RACING PRODUCTS, INC. 215 CLAY ST. N.W. AUBURN, WA.
98001
253-939-1415 FAX 253-939-1416

50200 RaceScales Jr Scale Instructions

Operating Instructions

On/Off This button turns scale on or off whether running on

THE BATTERY OR POWER ADAPTER.

ZERO USED TO ZERO SELECTED SCALE SYSTEM.

To Zero all 4 wheels with 1 push, select all 4 wheels

(MAKE THEM BLINK)

CONTRAST THESE BUTTONS WILL LIGHTEN OR DARKEN DISPLAY FOR

EASIEST VIEWING, THE UP ARROW WILL LIGHTEN THE DISPLAY

AND THE DOWN ARROW WILL DARKEN THE DISPLAY

LF THIS READING IS CREATED BY THE LEFT FRONT CABLE

RF THIS READING IS CREATED BY THE RIGHT FRONT CABLE


LR This reading is created by the left rear cable

RR THIS READING IS CREATED BYT EH RIGHT REAR CABLE

Make sure your cables are plugged into the correct pads for proper weights

Zeroing is accomplished by selecting desired wheel locations. Selected locations are indicated by flashing numbers. It is usually necessary to select all 4 wheel locations during initial turn on.

BATTERY: The RaceScale Jr. is designed to be used off of the battery. The 110 Charger is to charge the system back up after use. By using the system plugged into 110 power during use may cause damage to the battery. The amount of use you should received from your scale on a full charge is 4 - 6 hours. When charging the unit you should allow 24 hours to charge to full battery capacity



WHEN THE WEIGHTS ARE BLINKING THIS MEANS THAT WHEEL IS SELECTED

You are now ready to scale your vehicle.

Place vehicle on scales.

If all 4 wheel locations are flashing the total weight will show & the % location will read 100%.

To check L.S. (left side) you will select or de-select the proper buttons so the 2 left side wheel locations are flashing. You will now see the combined weight of the L.S. wheels and thier % of the total.

Select and De-Select for any Information you want to see.

NOTE: Charge battery overnight at least once a month for optimum life of battery.